WEIGHT INDICATOR

3590E-AF08

WHEEL WEIGHING – AXLE WEIGHING

USER MANUAL

E-AF08_02_10.10_EN_U

INDEX

1. INTRODUCTION 4
2. MAIN TECHNICAL SPECIFICATIONS 5
2.1 ACCESSORIES AVAILABLE 6
2.2 SYMBOLS USED 6
3. INSTALLATION 7
3.1 CASE AND DIMENSIONS 7
3.2 POWER SUPPLY & START UP 7
3.3 TURNING ON PRINTER IN ENERGY SAVING MODE 8
4. FRONT PANEL KEYS AND DISPLAYS 9
4.1 FUNCTION OF THE KEYS 9
4.1.1 "2ndF" KEY: SECOND FUNCTION OF THE KEYS 11
4.1.2 ENTERING ALPHANUMERIC TEXT 12
4.1.3 DISABLING THE KEYBOARD 12
4.1.4 HELP MENU 13
4.1.5 INDICATOR CONNECTED TO PC KEYBOARD 13
4.2 FUNCTION DISPLAY 14
4.2.1 STATUS INDICATORS 14
4.2.2 BATTERY LEVEL INDICATION 16
4.2.3 "TILT" DEVICE 16
4.2.4 DISPLAYED DATA 17
5. SCALE MANAGEMENT 18
5.1 SET THE NUMBER OF ACTIVE SCALES 18
5.2 SELECTION OF SINGLE SCALE/SUM FUNCTION 18
5.3 “SUM” FUNCTION 19
5.4 SUM OF THE SELECTED SCALES 19
6. SCALE ZERO FUNCTIONS 20
6.1 OPERATION OF ZERO ON THE SINGLE SCALE 20
6.2 CYCLE OF ZERO ON ALL THE CONNECTED SCALES 20
7. TARE FUNCTIONS 20
7.1 TARE FUNCTION ON “WHEEL WEIGHING” MODE 20
7.2 TARE FUNCTION IN “AXLE WEIGHING” MODE 20
7.3 MANUAL CALCULATED TARE 21
7.4 TARE CANCELLATION 21
7.5 LOCKED/UNLOCKED/DISABLED TARE 21
7.6 LIMITATION OF THE TARE FUNCTIONS 21
7.7 TARE EXECUTION MODE OR DISABLING OF THE TARE 21
8. MULTIRANGE AND MULTIDIVISION FUNCTION 22
9. DISPLAY OF METRIC DATA (inFO) 22
10. FILLING IN THE INPUT TEXT 23
11. DATABASE 24
11.1 ENTERING ITEMS 24
11.2 MODIFICATION OF DATA 25
11.3 CANCELLATION OF DATA 25
11.4 PRINTING DATA 25
11.5 DATA SELECTION/UNSELECTION 25
11.6 ENTRY, MODIFICATION AND QUICK SELECTION OF ITEM 000 25
11.7 ALPHABETICAL RESEARCH 26
11.8 HELP 26
12. DATABASE ACCESS PASSWORD 26
13. WEIGHING AND TOTALISATION PROCEDURES 27
13.1 TOTALISATION TYPES 27
13.2 “WHEEL WEIGH”TOTALISATION TYPE 27
13.2.1 UPDATING TOTALS 27

13.2.2 CANCELLING LAST WEIGH....27
13.2.3 ENTRY OF COORDINATES FOR CALCULATING THE BARYCENTRE (OR CENTRE OF GRAVITY) 27
13.3 "AXLE WEIGH" TOTALISATION TYPE....29
13.3.1 UPDATING TOTALS....29
13.3.2 CANCELLING LAST WEIGH....29
13.3.3 ENTRY OF AXLE NUMBER FOR AUTOMATIC PRINTING OF PARTIAL TOTAL....29
13.4 SET TOTALISATION THRESHOLD....30
13.5 REENABLING THE PRINTING AND WEIGH....30
13.6 VISUALISATION AND CLEARING OF THE ACCUMULATED TOTALS....30
13.7 PROGRESSIVES....31
13.7.1 PROGRESSIVE DIGITS....31
13.7.2 TICKET PROGRESSIVE....31
13.7.3 LOT PROGRESSIVE....31
14. PRINTOUTS....31
14.1 LINKING OF THE FORMATS TO THE PRINT FUNCTIONS....33
14.2 NUMBER OF TICKET COPIES....34
14.3 PRINTING OF THE HEADING....34
14.4 REPETITION OF THE LAST EXECUTED PRINTOUT....34
14.5 DEFAULT PRINTING FORMATS....34
15. OTHER FUNCTIONS....35
15.1 DIAGNOSTIC PERIPHERALS....35
15.2 CALCULATOR....36
15.3 DISPLAY OF NET WEIGHT WITH SENSITIVITY X 10 (for testing use during calibration)....36
15.4SETTING DATE / TIME....36
15.5 NET ←→ GROSS SWITCH....37
15.6 SET-POINT FUNCTION....37
16. ALIBI MEMORY....40
16.1 READING OF THE WEIGHS CARRIED OUT....41
16.2 SERIAL COMMANDS FOR MANAGING THE ALIBI MEMORY:....41
16.2.1 REQUEST WEIGHT VALUE WITH WEIGH ID....41
16.2.2 STRING FORMAT (WEIGHT/ID)....42
16.2.3 WEIGH READING....42
16.2.4 ALIBI MEMORY CANCELLATION (only with non approved instrument)....42
17. MESSAGES....43
17.1 INSIDE THE SET-UP OR MENU....43
17.2 AT START-UP....44
17.3 IN WEIGHING....45
DECLARATION OF CONFORMITY....46
WARRANTY....46

This is a “Table of Contents preview” for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

http://the-checkout-tech.com : the biggest supplier of cash register and scale manuals on the net